




**QPP24BL,
QPP24NNSBL**



**QPP48HDBL,
QPP48HDVNSBL,
QPP48HDNNSBL**




**QAPP24BL,
QAPP24NNSBL**




**QAPP48HDBL,
QAPP48HDVNSBL,
QAPP48HDNNSBL**


1.




2.




3.



4.




Jack Module Removal



Jack Module Installation

Reference PN364* (10Gig) or PN403* (Cat 6), for jack module termination instructions.



* Denotes Instruction Sheet revision letter.

For Instructions in Local Languages
and Technical Support:

www.panduit.com/resources/install_maintain.asp

PANDUIT
www.panduit.com

E-mail:
techsupport@panduit.com

Phone:
866-405-6654